



Fire Damper Opener Operating Instructions



FiDO2

Maximum Duct Height: 18" (Type A) /16" (Type B)

Recommended Minimum Duct Size:

12" Wide X 10" High

Minimum Access Door Size: 8"x8"

Instructions

- Turn clockwise with ratchet or right-angle electric drill (NOT impact driver) with ratchet bit.
- Raise FiDO jaws completely to relieve pressure off fire link.
- Remove fire link, then lower FiDO jaws down to "exercise" fire damper.
- Slowly raise FiDO jaws back up, adjusting position to keep access to link clear.
- Reinstall or replace fire link.
- Lower FiDO jaws and remove FiDO from duct through access door.



Helpful Hints

- Keep fingers and hands out of fire damper blades' path except when jaws are completely raised and fire link is being removed/replaced.
- Keep bottom jaw ends "hooked" over far bottom lip of fire damper.
- On vertical ducts, be sure to attach FiDO with lanyard to keep from dropping down duct.
- As needed, re-apply rubber coating or adhesive tape on tips of FiDO jaws.